11/3/24, 10:24 AM Check Answers

## 10.4.3 Lab: Secure Access to a Switch 2

Candidate: Richard Habib ()
Time Spent: 02:17

Score:	0%
--------	----

## **Task Summary**

## **Required Actions**

- X Create the GameConsoles ACL
- X Create a MAC-based access control Show Details
- X Bind the GameConsoles ACL to all of the interfaces Show Details
- × Save the configuration

## Explanation



While completing this lab, use the following information:

• Configure the *GameConsoles* MAC-based access control entry (ACE) settings as follows:

Priority	Action	Destination MAC Address	Source MAC Address
1	Deny	Any	Value: <b>00041F111111</b> Mask: <b>000000111111</b>
2	Deny	Any	Value: <b>005042111111</b> Mask: <b>000000111111</b>
3	Deny	Any	Value: <b>000D3A111111</b> Mask: <b>000000111111</b>
4	Deny	Any	Value: <b>001315111111</b> Mask: <b>000000111111</b>
5	Deny	Any	Value: <b>0009BF111111</b> Mask: <b>000000111111</b>
6	Deny	Any	Value: <b>00125A111111</b> Mask: <b>000000111111</b>

Complete this lab as follows:

11/3/24, 10:24 AM Check Answers

- 1. Create the GameConsoles ACL.
  - a. From the Getting Started page, under Quick Access, select Create MAC-Based ACL.
  - b. Select Add.
  - c. In the ACL Name field, enter GameConsoles.
  - d. Select **Apply** and then select **Close**.
- 2. Create a MAC-based access control.
  - a. Select MAC-Based ACE Table.
  - b. Select **Add**.
  - c. Enter the *priority*.
  - d. Select the *action*.
  - e. For Destination MAC Address, make sure **Any** is selected.
  - f. For Source MAC Address, select **User Defined**.
  - g. Enter the source MAC address value.
  - h. Enter the source MAC address mask.
  - i. Select **Apply**.
  - j. Repeat steps 2c-2i for the remaining ACE entries.
  - k. Select Close.
- 3. Bind the GameConsoles ACL to all of the interfaces.
  - a. From the left pane, under Access Control, select ACL Binding (Port).
  - b. Select **GE1**.
  - c. At the bottom of the window, select Edit.
  - d. Select Select MAC-Based ACL.
  - e. Select **Apply** and then select **Close**.
  - f. Select Copy Settings.
  - g. In the Copy configuration's to field, enter 2-30.
  - h. Select Apply.
- 4. Save the Configuration.
  - a. From the top of the window, select Save.
  - b. Under Source File Name, make sure Running configuration is selected.
  - c. Under *Destination File Name*, make sure **Startup configuration** is selected.
  - d. Select Apply.
  - e. Select **OK**.