11/25/24, 11:19 AM Check Answers

12.3.9 Lab: Secure an Enterprise Wireless Network

Candidate: Richard Habib ()
Time Spent: 02:41

Score:	0%
--------	----

Task Summary

Required Actions

- X Change admin username and password Show Details
- X Enable MAC address filtering Show Details
- X Configure access controls Show Details

Explanation



To complete this lab, use the following MAC addresses:

- 00:18:DE:01:34:67
- 00:18:DE:22:55:99
- 00:02:2D:23:56:89
- 00:02:2D:44:66:88

Complete this lab as follows:

- 1. Log into the Ruckus Wireless ZoneDirector.
 - a. In the Google Chrome URL field, type 192.168.0.6 and press Enter.
 - b. Log in using the following:
 - Admin Name: admin
 - Password: password
 - c. Select Login.
- 2. Change the admin's username and password for the Ruckus Wireless ZoneDirector.
 - a. Select the Administer tab.
 - b. Ensure Authenticate using the admin name and password is selected.
 - c. In the Admin Name field, enter WxAdmin
 - d. Enter password in the Current Password field.
 - e. In the New Password field, enter ZDAdminsOnly!\$ (Note: O is the capital letter O).
 - f. Enter ZDAdminsOnly!\$ in the Confirm New Password field.
 - g. On the right of the section, select Apply.
- 3. Enable MAC address filtering.
 - a. From the top, select the **Configure** tab.
 - b. From the left menu, select Access Control.
 - c. Expand L2-L7 Access Control.

11/25/24, 11:19 AM Check Answers

d. Under L2/MAC address Access Control, select Create New.

- e. In the Name field, enter Allowed Devices.
- f. Under Restriction, make sure **Only allow all stations listed below** is selected.
- g. Enter a *MAC address*.
- h. Select **Create New**.
- i. Repeat steps 3g-3h for each of the remaining MAC addresses that need to be added to the ACL.
- j. Select **OK**.
- 4. Configure access controls.
 - a. Under Access Control, expand Device Access Policy.
 - b. Select **Create New**.
 - c. In the Name field, enter **NoGames**.
 - d. Select **Create New**.
 - e. Use the OS/Type drop-down menu to select Gaming.
 - f. Use the Type drop-down menu to select **Deny**.
 - g. Under Uplink, ensure **Disabled** is selected.
 - h. Under Downlink, ensure **Disabled** is selected.
 - i. Select **Save**.
 - j. Select **OK**.